

Legacy Series Humidifier Residential Whole-House

GeneralAire® Model GF-1042DMM/DMD Flow Through Humidifier

Control Indoor Humidity.

Installing a GeneralAire® Whole House Humidifier can reduce allergy and asthma symptoms, minimize risk of infection, protect valuables (such as furniture, woodwork and musical instruments) and save you money.







How The GF-1042DMM Works:

Your furnace sends warm air through a water-soaked Vapor Pad® inside your humidifier, where it absorbs additional moisture. Newly-moistened air is then distributed throughout your home to provide healthier indoor air for you and your family.

Maintenance

Maintenance of your new GeneralAire® GF-1042DMM Legacy Series Flow Through Humidifier is minimal. To ensure peak performance and reliable operation, simply deposits from the water distribution trough and drain pan. The following solution is recommended: 1/2 water and 1/2 vinegar.

Install A Humidifier In Your Home To:

Protect Your Family's Health:

Low humidity is where viruses can thrive and cause your throat and nasal passages to dry. This leads to nose bleeds, increased risk of infection, colds, flu and other respiratory ailments. Dry air can trigger asthma and allergy symptoms. Air that's too dry causes dry/ itchy/cracked skin.

Protect Your Valuables:

Dry air in your home can cause expensive artwork, wood flooring, cabinets, furniture and musical instruments to crack. Dry air increases annoying static shocks that can damage electronics.

Save Money:

Since dry air can cause woodwork to crack, resulting gaps in windows & doors let cold outside air in. In addition, dry air feels colder. Take the chill out with a 1042LH. Turn your thermostat down and save money.

Why A Whole-House Unit?

- Treats Your Whole House 24 / 7 / 365

- Quiet

Our Brands GeneralAire







Toronto, ON M1P 3A9 Canada Toll Free: (888) 216-9184 www.generalaireiag.ca sales@GeneralAirelAQ.ca

400 Midwest Rd.

Last Updated: 01-2022





Legacy Series Humidifier

Residential Whole-House

GeneralAire® Model GF-1042DMM/DMD Flow Through Humidifier



Designed & Assembled in Michigan, USA

Cover Removal Screws (2)

- Remove screws, lift off water distribution tube and trough to replace Vapor Pad®.

Metal Water Distribution Tube

- Delivers water to the water distribution trough.

Cover

- Made with an ultra-violet stable automotive-grade plastic for longlasting durability.

Inspection Window

- Simply remove the GeneralAire® badge.

Sturdy Drain Pan

Quiet Operation

- You'll forget it's there!

Water Distribution Trough

- Distributes water evenly throughout GF-990:13 Vapor Pad® for maximum evaporation.

Stainless Steel Water Distribution Tube

- Brings (hot or cold) water into the unit.

Damper Control Knob

- Open during use.

Water Drain Tube

- Water is automatically drains from your humidifier.



Included **GF-MHX3 Manual Humidistat**

Your new GF-1042DMM comes with an easy-to-use GF-MHX3 humidistat. humidity, or to the right for less.



Replacement Vapor Pad®

- GFI #7919: GA900
- For optimal performance, replace your Vapor Pad® at the beginning of each heating season, and again mid-season.

Easy to install. Easier to

The Comprehensive Approach to Indoor Air Quality

Creating a healthy indoor air environment requires a comprehensive particulate removal are equally important components of that plan.

Install a Second Wind™ UV Air Purifier to degrade bacteria, germs, viruses, mold, mildew, VOC's, and other infectious diseases. The Second Wind™ SF-2000/2018 features photocatalytic oxidation with singlet oxygen to provide germicidal purification throughout your

Contact your local contractor to learn more about how to create a healthier and more comfortable home for you and your family. And visit us at www.GeneralAirelAQ.ca for more information on indoor air quality.



Our Brands GeneralAire



Last Updated: 01-2022



400 Midwest Rd. Toronto, ON M1P 3A9 Canada Toll Free: (888) 216-9184 www.generalaireiag.ca sales@GeneralAirelAQ.ca